

KATALYST

Beach Trolley



Beach Trolley kit includes
2x Trolley Arms
2x Beach Wheels
2x Beach Axles

1. Fit the axle to the wheel so the black cap is on the outside of the wheel.



2. Fit the axle to the trolley arm.



3. Remove the blue cap from the rear hole in the rear spar.



4. Lift the hull with the rear hull handle and slide the trolley into the rear hole in the rear spar.



5. Pull bungee loop out the front of the trolley arm and secure over spar tri knob.
6. Repeat step 3,4 & 5 for the other hull.



7. Stand at the rear of the boat holding both hull handles, lift the boat and the trolley wheels will swing forward.
8. Now trundle your Katalyst down to the water and go sailing (don't lift the bow too high or the stern will hit the ground).
9. The trolley arms will pack into your rudder bag and fit inside your hulls, wedge the wheels forward, one in each hull.

NB. It is possible to run your blokart wheels as trolley wheels.

